

PLEASE MAKE SURE TO INSTALL THE NEW VERTICAL MOUNTING STABILIZER BAR TO THE SUPER FLOW BY USING THE APPROPRIATE SIZE U-BOLT OR WELDING IT TO THE TOOLBAR RIGHT BESIDE THE VERTICAL SUPER FLOW. THEN SECURE THE SUPER FLOW BY ATTACHING THE PROVIDED U-BOLT TO THE STABILIZER BAR WITH THE LOCK WASHERS AND NUTS.

NOT DOING SO MIGHT WEAKEN THE UNIT AND CRACK DUE TO EXCESSIVE VIBRATION.



Install vertical stabilizer bracket like the photo to the left. Make sure the bracket is flush with the heat exchanger.



Make sure to install vertical mounting bracket flush with the mounting bracket for the super flow. Weld or use U-bolts to attach the vertical mounting bracket to the tool bar.



Secure the super flow to the vertical mounting bracket with the supplied U-bolts, lock washer and nuts and tighten firmly.